Milker Unit Accessories

For additional claw parts—see claw breakdown in the Parts Breakdown Section.

Pulsator Spring Gauge

Used to determine maximum and minimum length for the pulsator spring.

Order #: MZ10008

Pulsator Spring

Used in all NuPulse® claws. To check for maximum & minimum requirements, use spring gauge.

Order #: MZ10007

Square Base 'O' Ring

Fits on the base—between the bowl & middle of the Standard (One Line) Claws, including Goat Claw.

Order #: MZ10017

Middle 'O' Ring

Fits on the middle—between the middle & dome of all NuPulse® claws.

Order #: MZ10014

Claw Protector Seal

Fits on the outside rim of the middle to prevent dirt build-up between the middle and the bowl.

Order #: MZ10030

Note: Not required on Goat Claws

Bobbin Housing Seal

The bobbin seal fits on the bottom of the bobbin housing and creates a seal between the middle and the pulsator parts.

Order #: MZ10015

MLX Diaphragm

Fits between the base and the middle of the MLX (Two Line) Claw. Used for both Original MLX and FulFlo MLX models.

Order#: MZ10069

Pricker

Used in cleaning air bleed holes in the pulsator bobbin and MLX air bleed hole in bowl.

Order #: MZ10020